



Scan w/camera phone

Cast Kit - Short Arm - Plaster

Contact for pricing

Short Arm Cast (Plaster) - including the wrist, ending before the elbow

- 4 Rolls of 2" Fiberglass (Scotchcast) Cast Tape
- 4 Rolls of 4" Undercast Padding
- 2 feet of 3" Stockinet Sock

from [A1 Medical Integration](#) in North Hollywood, CA

Size

Qty 1

Condition Good

SKU

Questions? Call (818) 753-0319

or email sales@a1props.com

[Go to this item on propcart.web.app](#)